

Wireless Key Fob Activated Boat Lift Flood Light MODEL: LL-BLFL-KIT-WIRELESS



Items Needed To Assemble:

Wireless Key Fob Flood Light

- | | |
|------------------------------------|---------------------------------|
| 1. Flood Light | 6. Hose Clamps |
| 2. Extension Wire | 7. Zip Ties |
| 3. Wireless Controller and Key Fob | 8. Mounting Hardware & Grommets |
| 4. Battery Connector Wire | |
| 5. Mounting Arm | |



Lake Lite Inc.
105 W. Simon St.
Laotto, IN 46763

Phone: 260-918-2758
Fax: 260-918-3540
E-mail sales@lakelite.com

www.lakelite.com

Wireless Key Fob Activated Boat Lift Flood Light

MODEL: LL-BLFL-KIT-WIRELESS



Lake Lite Inc.
105 W. Simon St.
Laotto, IN 46763

Phone: 260-918-2758
Fax: 260-918-3540
E-mail sales@lakelite.com

www.lakelite.com

Wireless Key Fob Activated Boat Lift Flood Light MODEL: LL-BLFL-KIT-WIRELESS



WARNING

**YOU MUST CONNECT THE RF RECEIVER PROPERLY.
CONNECTING BACKWARDS MAY CAUSE DAMAGE TO
THE RECEIVER.**

**POWER =
BATTERY SIDE**

**LED =
EXTENSION
WIRE**



PO BOX 414
105 W. Simon St.
Laotto, IN 46763

Phone: 260-918-2758
Fax: 260-918-3540
E-mail sales@lakelite.com

www.lakelite.com