


Standard Control Box Panel


Upgrades a 1-Valve or 2-Valve Triton Pro Push Button Control Box to a Wireless Pro + Leak Guard Protection




AUTO 3-Tank Stabilizing Control Panel

Upgrades a 2-Valve Triton Pro Push Button Control Box to Wireless Pro + Leak Guard.

Time differential center tank control maintains stability on outside tanks while lifting/lowering.



Valve A air hose is split to the outside tanks.
Valve B air hose goes to the center tank.




HIS & HERS 2-Lift Control Panel

Independently control TWO separate lifts from the SAME controller.



(Eliminates need of 2nd control box)

Upgrades a 2-Valve 2-Lift Triton Pro Push Button Control Box to a Wireless Pro + Leak Guard Protection




Valve A air hose is split to boat lift A.
Valve B air hose is split to boat lift B.







Valve A air hose splits to all tanks



Valve A air hose splits to all tanks





Standard Control Panel



Valve A air hose is split to the outside tanks.
Valve B air hose goes to the center tank.



AUTO 3-Tank Stabilizing Control Panel



Valve A air hose is split to boat lift A.
Valve B air hose is split to boat lift B.



HIS & HERS 2-Lift Control Panel