


# Standard Control Box Panel



*Upgrades a 1-Valve or 2-Valve Ultra Lift Push Button Control Box to a Wireless Pro + Leak Guard Protection*



# AUTO 3-Tank Stabilizing Control Panel


*Upgrades a 2-Valve Ultra Lift Push Button Control Box to Wireless Pro + Leak Guard.*

*Time differential center tank control maintains stability on outside tanks while lifting/lowering.*



Valve A air hose is split to the outside tanks.  
Valve B air hose goes to the center tank.






Valve A air hose is split to boat lift A.  
Valve B air hose is split to boat lift B.


# HIS & HERS 2-Lift Control Panel

*Independently control TWO separate lifts from the SAME controller.*

*(Eliminates need of 2<sup>nd</sup> control box)*

*Upgrades a 2-Valve 2-Lift Ultra Lift Push Button Control Box to a Wireless Pro + Leak Guard Protection*






OR



Valve A

Valve A air hose splits to all tanks




Valve A

Valve A air hose splits to all tanks



**Standard Control Panel**



Valve A


Valve A air hose is split to the outside tanks.  
Valve B air hose goes to the center tank.



Valve B



**AUTO 3-Tank Stabilizing Control Panel**



Valve A

Valve A air hose is split to boat lift A.  
Valve B air hose is split to boat lift B.



Valve B



**HIS & HERS 2-Lift Control Panel**