

## **Optional: Running Solar Wire in Conduit**

For boat house installations, local Inspectors & Authorities Having Jurisdiction may require the solar panel wire installed inside conduit to the battery box. Please see some recommended installation ideas and techniques.





Feed solar panel wire through mounting arm then into <sup>3</sup>/<sub>4</sub>" liquid tight conduit. Next press the conduit into the hole as shown.



Example: Solar Panel Mounting Arm with ¾" Liquid tight Conduit



## **Optional: Running Solar Wire in Conduit**

For boat house installations, local Inspectors & Authorities Having Jurisdiction may require the solar panel wire installed inside conduit to the battery box. Please see some recommended installation ideas and techniques.





Decide the best location for the wire to enter the box for your application. The hole should be drilled just under the box lip as shown. For best results, use a 1-1/8" hole saw style drill bit to make a clean hole.

## Mount the connector





Mount the conduit connector to the hole and securely tighten the nut to provide a water tight seal.



**Choose Connector Type** 

## Example: Finished Battery Box Installation with <sup>3</sup>/<sub>4</sub>" Liquid tight Conduit



The liquid tight conduit will run between the battery box and the solar panel.